## HMI colour touch panel



### Description

BTM panels are completely configurable HMI touch devices available in three models, 7", 10" and 15.6".

The 7" and 10" models have a resistive touchscreen, the 15" has a capacitive unit.

They can be configured by means of the dedicated BTM-PC-IDE software that offers a wide range of widgets and communication protocols to develop projects that meet all the user requirements in several applications.

BTM panels come with Ethernet, serial and USB ports that match a wide range of use cases.

They are fully integrated into the UWP 3.0 ecosystem which includes a complete range of meters, sensors and actuators.



• **High-performing** device with a powerful CPU for a wide range of applications in building automation and energy monitoring.

CARLO GAVAZZI

• **High definition TFT widescreen (16:9)** color touch panel with dimmable LED backlight available in three different sizes.

• **Fully programmable** by the dedicated IDE software with a vast library of widgets, functions and communication protocols.

• Connectable to UWP 3.0 and to third-party field devices via BACnet IP, BACnet MS/TP or Modbus TCP/IP, Modbus RTU and KNX IP.

• Interoperability: IIoT data distribution via MQTT and OPC UA.

• **Reliability**: Industrial grade hardware powered by Linux OS.

## Applications

## Monitoring and active control for building automation

The BTM panel can be connected to the UWP 3.0 controller via Modbus TCP/IP, RTU or via BACnet IP to manage and control, as a powerful HMI interface, all the building automation functions (i.e. lighting control, HVAC regulation, fire dampers, alarms handling and others). The parameters of the functions can be imported easily to the IDE software from the Modbus map or the BACnet EDE files generated from the UWP 3.0 Tool. This way, user can link those functions to the widgets available in the Widgets Gallery.

The BTM panel can also be connected to third-party devices, by using the available communication protocols, the connection to SCADA or the BMS systems.



## Data logging and data automation with local display for grouping meters data into a switchgear or a machine

The BTM panel can be installed in a cabinet and connected to energy meters or analyzers to read the variables and the alarm events about electric, water or gas consumptions. Such data can be analyzed, aggregated, or displayed in trends, bar graphs or digital dashboards on the BTM screens, according to the user's requirements. The measurement data collected and stored can be saved, exported or exchanged with other systems via FTP, SMTP or by using the available protocols.

#### Local and remote custom dashboards

The integrated web server allows users to access HMI and web HMI projects via standard web browsers or mobile devices such as tablets or smart-phones. Users can create HTML5-based web projects to show the graphical pages displayed locally on the BTM screen so to provide remote access to the system.



#### Main functions

- · Local HMI and remote Web-HMI for custom dashboards
- Data logger and gateway for creating data automation solutions

• IIoT Edge device for interfacing the field and the Cloud via secure protocols and OPC UA or MQTT standards



#### Main features

#### Protocols and communication

- Connectible to the UWP 3.0 controller via Modbus TCP/IP, Modbus RTU and BACnet IP
- Connectible to third-party devices via Modbus TCP/IP, Modbus RTU, BACnet IP, BACnet MS/TP, KNX IP and KNX TP\*
- Up to 32 Modbus devices connectible to the RS485 port
- Remote monitoring and control with MAIA Cloud\*\*
- OPC UA server / client for Industry 4.0 applications to exchange data among HMI, PLC and equipments.

• MQTT service for IIoT messaging compatible with any MQTT broker, including those offered by providers such as Amazon, Microsoft, IBM, Microsoft.

\*through an expansion optional module for BTM-T15-PLUS \*\*MAIA Cloud will be available from 2022

#### Web capabilities

- Integrated web HMI with HTML5 and Javascript support
- · Custom web interface with user's permission management



## BTM-Txx-RSE structure




Fig. 1 Structure

| Area | Description  |
|------|--|
| Α    | Power supply   |
| В    | Serial port  |
| С    | Ethernet port 0 (10/100 Mb)                                |
| D    | USB port   |
| E    | Holes for fixing brackets: 4x BTM-T7-RSE / 11x BTM-T10-RSE |
|      | Note: the fixing brackets are included                     |



## BTM-T15-RSE structure




Fig. 2 Structure

| Area | Description   |
|------|---|
| Α    | Power supply  |
| В    | Ethernet port 0 (10/100 Mb)   |
| С    | Serial port   |
| D    | Ethernet port 1 and 2 (10/100 Mb)   |
| Е    | USB port 1 and 2  |
| F    | Holes for fixing brackets: 4x BTM-T7-RSE / 11x BTM-T10-RSE   Note: the fixing brackets are included |
| G    | Expansion slots for plug-in module (I/O module)   |
| н    | SD Card slot  |





## **Features**



General

| Model              | BTM-T7-RSE | BTM-T10-RSE               | BTM-T15-PLUS  |
|--------------------|------------|---------------------------|---------------|
| Material           | PI         | Aluminum                  |               |
| Dimensions (HxWxD) | See fig. 1 |                           | See fig. 2    |
| Weight             | 0.6 Kg     | 1.0 Kg                    | 4.1 Kg        |
| Colour             | Black      | Black                     | Grey (back)   |
|                    |            |                           | Black (front) |
| Protection degree  |            | IP66 (front), IP20 (back) |               |




Fig. 3 Dimensions BTM-Txx-RSE

| Model       | L                  | Н                 | D                | А                  | В                 | Т               |
|-------------|--------------------|-------------------|------------------|--------------------|-------------------|-----------------|
| BTM-T7-RSE  | 187 mm / 7.36"     | 147 mm /<br>5.79" | 29 mm /<br>1.14" | 176 mm / 6.90"     | 136 mm /<br>5.35" | 5 mm /<br>0.19" |
| BTM-T10-RSE | 282 mm /<br>11.10" | 197 mm /<br>7.75" | 29 mm /<br>1.14" | 271 mm /<br>10.66" | 186 mm /<br>7.32" | 6 mm /<br>0.23" |




Fig. 4 Dimensions BTM-T15-PLUS

| Model        | L               | Н               | D              | А               | В               |
|--------------|-----------------|-----------------|----------------|-----------------|-----------------|
| BTM-T15-PLUS | 422 mm / 16.60" | 267 mm / 10.50" | 56 mm / 02.20" | 411 mm / 16.18" | 256 mm / 10.00" |

## Environmental specifications

| Model                 | BTM-T7-RSE     | BTM-T10-RSE              | BTM-T15-PLUS   |
|-----------------------|----------------|--------------------------|----------------|
| Operating temperature | 0° to 50°C     |                          | -20°C to +60°C |
| Storage temperature   | -20°C to +70°C |                          |                |
| Humidity              | from           | 5 to 85% R.H. non-conden | sing           |

| Compatibility and conformity  |  |  |  |  |  |  |
|-------------------------------|--|--|--|--|--|--|
| Model BTM-T7-RSE BTM-T15-PLUS |  |  |  |  |  |  |
| CE                            | Emission EN 61000-6-3 for installation in residential environments<br>EN 61000-6-2 for installation in industrial environments |  |  |  |  |  |
| CUL US<br>LISTED              | cULus: UL508<br>cULus: Class 1 Div 2   | cULus: UL61010-1 / UL61010-2-<br>201<br>cULus: Class 1 Div 2 |  |  |  |  |





|   | _   |
|---|-----|
|   | - 6 |
|   | _   |
| - |     |
|   |     |

## Power supply

| Model                          | BTM-T7-RSE   | BTM-<br>T10-RSE | BTM-T15-PLUS   |  |
|--------------------------------|--|-----------------|--|--|
| Power supply                   | 24 V dc: 10-32 V dc  |                 |  |  |
| Max. current consumption to 24 | 0.3 A  | 0.38 A          | 1.2 A  |  |
| V dc                           | Note: Make sure the power supply has enough power capacity for the device to work. |                 |  |  |
| Input protection               | Automa   | itic            | Electronic   |  |
| RTC backup                     | Yes (super capacitor)  |                 | 1 metal lithium battery (3V 50 mAh), rechargeable, not replaceable by the user, model VL2330; 0.03g.   |  |
| Battery recharge               |  |                 | At the first installation, the battery must be charged for<br>48 hours. When the battery is fully charged, it guar-<br>antees a 3-month period of data backup at 25° C |  |

Note: the BTM-T15-PLUS model contains 1 metal lithium battery. For the sending, you must comply with the relevant packaging and labeling regulations.

## System resources

| Model                                   | BTM-T7-RSE                                    | BTM-T10-RSE | BTM-T15-PLUS                                     |  |
|---|---|-------------|--|--|
| Display - colour                        | 7" TFT 16:9 - 64 10.1" TFT 16:9 - 64 1<br>K K |             | 15.6" TFT LED - 16 M                             |  |
| Resolution                              | 800 x 480, 1024 x 600, WVGA 7                 |             | 1366 x 768, HD                                   |  |
| Brightness                              | 200 Cd/m2 typ.                                |             | 400 Cd/m2 typ.                                   |  |
| Dimming                                 | Yes   |             | to 0%  |  |
| Touchscreen                             |   |             | True glass Projected Capacitive, Multi-<br>touch |  |
| CPU                                     | ARM Cortex-A8 1 GHz                           |             | ARM Cortex-A9 quad-core 800 MHz                  |  |
| Operating system                        | Linux 3.12                                    |             | Linux RT   |  |
| Flash                                   | 4 GB  |             | 8 GB   |  |
| RAM                                     | 512 MB  |             | 2 GB   |  |
| Real Time Clock, RTC Back-up,<br>Buzzer | Yes   |             |  |  |

## **BTM Studio Suite**

BTM Studio is a software suite that includes the following applications.



It is an integrated development environment for easily designing and managing custom HMI thanks to a large embedded library of widgets. A unified design approach for native and web HMI projects that permits user to create pages optimized for display on the BTM panels, XAP 1.0, BTM-PC-RUNTIME and any web client (PC or smart devices). The design and management can be carried out in a single development environment so to reduce the application development and maintenance costs.



BTM-PC-CLIENT is a standalone application that provides remote access to the BTM panels, XAP 1.0 and PC on which the BTM-PC-RUNTIME is operating. It is a lightweight Microsoft® Windows® application released for free in the BTM Studio suite. BTM-PC-CLIENT acts as remote client and communicates with the Runtime software. This way, users can view the HMI project on the BTM panel or BTM-PC-RUNTIME on the same network, even if they are installed in different installation locations.



It is a powerful application that turns the Microsoft® Windows® computer into a HMI panel. This is the Windows® version of the HMI Runtime software that operates on the BTM panels. The BTM-PC-RUNTIME provides a set of HMI and data automation features of the BTM panels with a PC flexibility and expandability. BTM-PC-IDE permits user to design and manage the BTM-PC-RUNTIME projects.

\*You need a BTM-PC-RUNTIME software license for any PC on which the Runtime operates.

The BTM-PC-IDE software provides the following key-features for the areas presented below:

### **Design and UI experience**

• It provides a widget gallery with a lot of symbols and vector objects and native support of SVG graphical objects and TrueType fonts.

• The data can be numbers, texts, bar graphs, analog indicators and graphical image formats for a high user interface experience.

• Users can change the properties of basic and advanced widgets. The widgets can be managed dynamically to control their visibility, transparency, position and other features.

• The HMI and web projects can be easily created and managed in multiple languages so to meet global requirements.

• A rich set of state-of-the-art HMI features permits to create a fully operational application for data acquisition and recording, presentation of trends, alarm management, schedulers, security and user management, e-mail.



- On-/Offline simulation to test HMI project on real time.
- Efficient scripting tool to create embedded functions.

## **Communication protocols**

- A wide communication protocols permits user to meet all the different applications' requirements.
- Thanks to the gateway/routing capabilities, the communication among different communication protocols is possible.

• Easy integration into the UWP 3.0 ecosystem through plug'n play import of Modbus maps and EDE BACnet files.

## Design and planning

• The same tool software for the development and management of the HMI / HMI web projects and data automation for BTM panels, XAP 1.0 and BTM-PC-RUNTIME.

| Resource   | BTM Panels | BTM-PC-RUNTIME |
|--|------------|----------------|
| Data points  |            | 10.000         |
| Schedulers   |            | 30             |
| Alarms   | 2.000      | 10.000         |
| Data transfer items (conversion between different protocols) |            | 1.000          |
| Actions programmable per button state                        |            | 32             |
| Trend buffers  |            | 30             |
| Tags per trend buffer  |            | 200            |
| Number of curves per trend widget                            |            | 5              |
| Number of physical protocols                                 |            | 4              |
| Widget   |            |                |
| Basic widgets  | 20         | 00 per page    |
| Recipes  |            | 32             |
| Parameter sets for a recipe                                  |            | 1.000          |
| Elements per Recipe  | 1.000      |                |
|  |            |                |
| Pages and pop-up   |            |                |
| Pages  |            | 1000           |
| Dialogue pages (pop-up)                                      |            | 50             |
| Dialogue pages that can be opened at the same time           |            | 5              |
| Number of templates pages                                    |            | 50             |
| Number of languages  |            | 24             |
| User and Groups  |            |                |

Below the resources table for HMI projects:



| Resource                            | BTM Panels | BTM-PC-RUNTIME |
|-------------------------------------|------------|----------------|
| Number of user groups               |            | 50             |
| Number of users                     |            | 500            |
| Number of concurrent remote clients |            | 4              |
|                                     |            |                |
| JavaScript                          |            | YES            |
| Concurrent FTP sessions             |            | 4              |
| FTP additional folders              |            | 5              |
| PDF report generation               |            | YES            |

## Configuration

Connect the BTM panel to the computer with an Ethernet connection and power it on. To access the settings page of the panel, enter the following parameters in a browser:

| Parameters | Default value                     |  |
|------------|-----------------------------------|--|
| Settings   | nttps://ip_address/machine_config |  |
| Username   | admin                             |  |
| Password   | Gav@zzi!2015                      |  |

By default the Ethernet ports are configured as follows:


| Port        | Default settings                                  |  |
|-------------|---|--|
| ETH0 / WAN  | DHCP  |  |
| ETH2 / LAN* | DHCP  |  |
| ETH2 / LAN* | IP Address 192.168.0.1 Subnet mask: 255.255.255.0 |  |

Note: (only for BTM-T15-PLUS model)


| System Settings |   | Language | ADMIN 🕞 |
|-----------------|---|----------|---------|
| Language        | R | English  | *       |
| System          |   | Italiano |         |
| Logs            |   | Deutsch  | -       |
| Date & Time     |   | 中文       | 2       |
| Network         |   |          |         |
| Services        |   |          |         |
| Management      |   |          |         |
| Display         |   |          |         |
| Restart         |   |          |         |
| Authentication  |   |          |         |



## **Connection Diagrams**




## Fig. 5 Power supply



To operate in RS485 pins 4-3 and 8-7 must be connected externally.

| Pin | RS485      | RS422 | RS232 |
|-----|------------|-------|-------|
| 1   | GND        |       |       |
| 2   |            |       |       |
| 3   | CHA-       | CHA-  | ТΧ    |
| 4   | CHB-       | CHB-  | RX    |
| 5   |            |       |       |
| 6   | +5V output |       |       |
| 7   | CHB+       | CHB+  | CTS   |
| 8   | CHA+       | CHA+  | RTS   |
| 9   |            |       |       |

Fig. 6 Serial port pinout BTM-Txx-RSE



To operate in RS-485 pins 1-2 and 3-4 must be connected externally.

| Pin | RS485      | RS422 | RS232 |
|-----|------------|-------|-------|
| 1   | CHA-       | CHB-  | RX    |
| 2   | СНВ-       | CHA-  | ТХ    |
| 3   | CHB+       | CHB+  | CTS   |
| 4   | CHA+       | CHA+  | RTS   |
| 5   | +5V output |       |       |
| 6   | GND        |       |       |
| 7   |            |       |       |
| 8   | SHIELD     |       |       |

Fig. 7 Serial port pinout BTM-T15-PLUS



## **Connection diagram for RS485**




Fig. 8 Connection diagram for RS485\*\*






Fig. 9 Connection diagram for RS485\*\*

\*The serial port is software programmable. Make sure you select the appropriate interface in the programming software.

\*\*It can be used as reference when the pinout of the PLC is not known.

Note: different electrical standards are available for the signals in the PLC port connector: RS-232, RS-422, RS-485.



## References

## Further readings

| Information         | Document     | Where to find it |
|---------------------|--------------|------------------|
| BTM Studio manual   | User manual  |                  |
| Installation manual | BTM-T7-RSE   |                  |
|                     | BTM-T10-RSE  |                  |
|                     | BTM-T15-PLUS |                  |



## Order code

| Component name/code | Description   |  |
|---------------------|---|--|
| BTM-T7-RSE          | HMI 7" colour display with resistive touchscreen, 1 Ethernet, 1 Serial, 1 USB     |  |
| BTM-T10-RSE         | HMI 10.1" colour display with resistive touchscreen, 1 Ethernet, 1 Serial, 1 USB  |  |
| BTM-T15-PLUS        | HMI 15.6" colour display with capacitive touchscreen, 3 Ethernet, 1 Serial, 2 USB |  |

### Accessories

| Component name/code | Description   |  |
|---------------------|---|--|
| BTM-T7-BOX1         | Wall mounting box for BTM-T7-RSE                                      |  |
| BTM-T10-BOX1        | Wall mounting box for BTM-T10-RSE                                     |  |
| BTM-KNX             | Plug-in KNX module for BTM-T15-PLUS and for the XAP10RSEXX controller |  |

#### Software

| Component name/code | Description                                     |
|---------------------|---|
| BTM-PC-IDE-LICENCE  | BTM-PC-IDE licence code                         |
| BTM-PC-RT-LICENCE   | BTM-PC-RUNTIME licence code                     |
| BTM-PC-CLIENT       | Microsoft® Windows® freeware client application |

## CARLO GAVAZZI compatible components

| Scope               | Component name/code | Notes                   |
|---------------------|---------------------|-------------------------|
| Monitor and control | UWP30RSEXXX         | See relevant data sheet |



## COPYRIGHT ©2021

Content subject to change. Download the PDF: www.productselection.net